

|  |  |  |  |  |  |  |  |  |  |  |  |   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |
|--|--|--|--|--|--|--|--|--|--|--|--|---|--|--|--|-------------------|--|--|--|--|--|--|--|--|--|--|--|-------------------|--|--|--|-------------------|--|--|--|--|--|--|--|--|--|--|--|-------------------|--|--|--|-------------------|--|--|--|--|--|--|--|--|--|--|--|
|  |  |  |  |  |  |  |  |  |  |  |  |   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |
| <b>STEP 1</b><br>  |  |  |  |  |  |  |  |  |  |  |  | <b>STEP 2</b><br>   |  |  |  | <b>STEP 3</b><br> |  |  |  |  |  |  |  |  |  |  |  | <b>STEP 4</b><br> |  |  |  | <b>STEP 6</b><br> |  |  |  |  |  |  |  |  |  |  |  | <b>STEP 7</b><br> |  |  |  | <b>STEP 5</b><br> |  |  |  |  |  |  |  |  |  |  |  |
| <p>Attention: screw "F" should only be installed as the final step, after all assemblies and adjustments are complete.</p> |  |  |  |  |  |  |  |  |  |  |  | <p>NAME: Hinged Door Credenza<br/> TYPE: AVA-HDC2072<br/> SPECIFICATION: 72"W*20"D*29"H</p> |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |                   |  |  |  |                   |  |  |  |  |  |  |  |  |  |  |  |