



## ASSEMBLY INSTRUCTIONS MAYTRIX™ LAN FURNITURE 90° CORNER WORK SURFACE

NOTE: Please count and inspect all pieces before disposing of any carton or packing materials.

**COMPONENTS:** When ordering components, specific color and/or size information may be required. Contact a Mayline Customer Service Representative. 1-800-822-8037

<u>REF. #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART No.</u>	
1	1	TOP	CALL~~**	
2	1	L.H. SUPPORT BRACKET (LONG)	B3865**	** Denotes Color Code ~~Denotes Size
3	1	L.H. SUPPORT (SHORT)	B4381**	
4	1	R.H. SUPPORT BRACKET (LONG)	B3864**	
5	1	R.H. SUPPORT (SHORT)	B4382**	

HARDWARE BAG (PART No. A7119) \*for individual item, order that part number

<u>REF. #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
E1	14	#10 x 3/4 SCREW	X11*

1. Assemble Legs to Frames per instructions included with those components.
2. Select height desired for Work Surface (1) and install Left Brackets (2 & 3), Right Brackets (4 & 5).
3. Position Work Surface (1) on Brackets and install Screws (E1).

