


**CUT**

*Place this on WORKSURFACE*

**FOLD** along this line



*Place this over Worksurface EDGE*



**CUT** along this line

**CUT**

*Place this on WORKSURFACE*

**CUT**

**FOLD** along this line



*Place this over Worksurface EDGE*



**PENCIL STOP HOLE TEMPLATE:**

1. Cutout template to make 2 pieces.
2. Place arrow heads point to point. Tape 2 template pieces together. Distance between holes to be 14 inches
3. Fold template along designated fold lines.
4. Place template taped joint at center of the work surface (left to right) with the hole locators "DOWN"
5. Mark both hole locations.
6. Drill two holes: 1/8" dia. x 1/2" deep.