




TransAction™

Double Sided Workstation Power Kits
 TAETKD48A, TAETKD60A &
 TAETKD72A











ASSEMBLY INSTRUCTIONS
 CALL 1-800-822-8037 FOR ASSISTANCE

P/N **TAETKDA** 10/04/10


www.mayline.com

PARTS LIST


Name	Part	Qty.	Name	Part	Qty.
A	 Power Block	2	D	 Receptacle	16
B	 Mounting Bracket	2	E	 Screw #8-32 x 3/8	4
C	 Interconnecting Cable, 3.5" (48" Tables)	1	F	 Interconnecting Cable, 28"	1
	 Interconnecting Cable, 16" (60" Tables)				
	 Interconnecting Cable, 28" (72" Tables)				

IMPORTANT:
 Read all instructions before beginning job. These instructions are provided to avoid problems that may occur from improper assembly. The manufacturer and/or distributor are not responsible for failure resulting from improper assembly or installation. Moreover, all warranties are void for failure to follow these assembly instructions.


1. Install mounting bracket (B) to underside of table beam using screws (E).



2. Snap receptacles (D) into power block (A).



3. Slide power block (A) into mounting bracket (B).



4. Connect power blocks (A) using interconnect cables (C or F).

