

# ASSEMBLY INSTRUCTIONS

## TechWorks™ Organizer Frame

**NOTE:** Please count and inspect all pieces before disposing of any carton or packing materials.



**COMPONENTS:** When ordering components, specific color and/or size information may be required. Contact a Mayline Customer Service Representative. 1-800-822-8037



REF. #	QTY.	DESCRIPTION	PART No.
1	2	CROSS WAY	CALL~~**
2	2	UPRIGHT	CALL~~**
3	1, 2	CENTER UPRIGHT	CALL~~**
4	1	L.H. FOOT	B7683**
5	1	R.H. FOOT	B7684**

\*\* Denotes Color Code  
~~Denotes Size


**HARDWARE BAG (PART No. A7698)** \*for individual item, order that part number

REF. #	QTY	DESCRIPTION	PART No.
E1	17	#10 X 1 SCREW	X12*
E2	40	5/16-18 X 3/4 SCREW	X410*





1. Laying on a non-scatching surface, place Uprights (2 and 3) in Crossway (1) and attach using Screws (E2). Do not tighten Screws.



\*Be sure all upright trapezoidal holes are orientated in the same direction.



(1)

2. Place remaining Crossway (1) onto the opposite end of the Uprights (2 and 3) and attach using Screws (E2). Do not tighten.

3. Square the assembly by measuring diagonally.

4. Tighten all Screws (E2).




Fig. 2

5. Flip assembly over and install Screws (E2).




Fig. 3

(2)

6. Remove grommets from top of worksurface.

7. Place Organizer Frame Assembly onto worksurface and align grommet holes in Crossway (1) and attach using Screws (E1).




Fig. 4




Fig. 5

8. Attach Feet (4 and 5) to outer Uprights (2) using Screws (E2). Do Not Tighten.

9. Using Screws (E1) attach feet to worksurface by pushing feet tight against the upright. Making sure upright is perpendicular to floor.

10. Tighten Screws (E2).

11. Replace grommets into holes.