





ASSEMBLY INSTRUCTIONS

S D C Data Cabinet

When ordering components, specific color and/or size information may be required.
Contact a Mayline Customer Service Representative. 1-800-822-8037

NOTE: Please count and inspect all pieces before disposing of any carton or packing materials.

HARDWARE BAG (PART No. A6425) *for individual item, order that part number

<u>REF. #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART No.</u>	
E1	1	PULL	Q5021*	
E2	2	#10-24 X 3/8 SCREW	X5096*	
E3	4	GLIDE	Q588*	
E4	48	#10-32 CAGE NUT	T118*	
E5	48	#10-32 X 1/2 SCREW	X375*	


1. Install Glides (E3) into nearest to base corners. (When installing optional Casters use holes farthest from the corner).

NOTE:

For best internal cabinet access to glides – level cabinet prior to positioning Rack Mount Rails and installing shelves or equipment.

2. Attach Handle (E1) to front door with fasteners (E2).

3. Insert Cage Nuts (E4) as required to attach panels and / or accessories with screws (E5).



TO INSTALL CAGE NUTS:

- A.) Place bottom of Cage Nut through square hole from back side of rail (see detail at right), allowing the lower portion of Cage Nut to grip the rail.
- B.) Compress the upper portion of the Cage Nut with your thumb and snap Cage Nut into place.

TO REMOVE CAGE NUTS:

Compress Cage Nut with pliers.

NOTE:

Removal of the Cabinet Top Knockouts requires a sharp blow with a hammer.

