


ASSEMBLY INSTRUCTIONS

TRANSACTION LATERAL FILE RETURN



NOTE: Please count and inspect all pieces before disposing of any carton or packing materials.

COMPONENTS:



When ordering components, specific color and/or size information may be require
 Contact a Mayline Customer Service Representative. 1-800-822-8037

<u>REF. #</u>	<u>QTY.</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
1	1	WORK SURFACE	CALL~~**
2	1	LATERAL FILE	C841H**

** Denotes Color Code
 ~~Denotes Size

HARDWARE BAG (PART No. A8099) *for individual item, order that part number

<u>REF. #</u>	<u>QTY</u>	<u>DESCRIPTION</u>	<u>PART No.</u>
E1	17	#10 X 3/4 SCREW	X11*
E2	2	JOINING PLATE	B7522
E3	4	DOUBLE FACE TAPE	E515



1. Remove the Lateral File (2) from carton.
2. Adhere four pieces of Double Face Tape (E3) to top of Lateral File (2).
3. Position Worksurface (1) onto Lateral File (2) as desired. NOTE: Left Hand Return Shown.
4. Apply pressure to Worksurface (1) to provide a good bond with Double Face Tape (E3).

(1)

Assemble as shown for LEFT HAND Return

5. Attach Joining Plates (E2) to underside of existing desk worksurface using Screws (E1).
6. Slide Return into position and attach Joining Plates (E2) using Screws (E1).

